## **Article - Public Safety**

## [Previous][Next]

§12–912.

The owner or user of a boiler or pressure vessel shall:

- (1) ensure that the boiler or pressure vessel is operated, inspected, and repaired in accordance with this subtitle and regulations adopted under this subtitle;
- (2) maintain a copy of inspection, maintenance, and repair records at a central location in accordance with regulations adopted under this subtitle; and
- (3) make inspection, maintenance, and repair records available to the inspector required to inspect the boiler or pressure vessel.

[Previous][Next]